Poo Pit™

INSTALLATION GUIDE

SMARTSTREAM
TECHNOLOGY

1

Inspection & Preparation

- Inspect the Poo Pit™ for defects
- Prepare installation bed following regulations

2

Backfill and compact

- Connect to the Downstream Outlet

3

Preparation for installation of the access cover

- Set to the required level & pack bedding to support the product

4

Connect the Upstream Inlet(s) & the vertical riser

- Cut the riser
- Connect the vertical riser cap

5

Backfill & Install Access Cover

- Backfill and compact following regulations
- Install approved trafficable/non-trafficable cover following regulations